Ready2Talk

PA 2 System

Operation instructions

Thank you for purchasing the Ready2Talk PA 2 system. Once the system has been installed you're ready to go!

1. Turn on the switch on the front of the box and the red light will come on, tune the radio to FM 89.1 or 88.7 MHz. (whichever frequency the FM modulator was set for during installation)

2. Plug the microphone in to the socket on the top of the PA 2 and place the headset on your head with the microphone approximately 2 to 3 cm or 1" from your mouth

3. Turn up the volume on the radio to about 1/4 to 1/3 volume. It will need to be a bit higher than when you listen to the radio.

4. Adjust the knob on the PA 2 for microphone sensitivity, with the line on the gain knob pointing at the power indicator LED and start talking. If you need it louder, turn up the radio volume for the correct loudness.
5. **Please note!** The knob on the front of the PA Portable is **NOT a volume control; it is a microphone sensitivity control!** It's there to make up for differences in microphones and how loud you talk. Once you find the best gain setting all volume adjustments should be done by the radio volume

6. The PA 2 also allows you to connect your ipod, mp3, DVD or laptop into the PA system, so you can play music and talk at the same time. Plug your ipod into the input on the front of the PA Portable and adjust the volume on your ipod to desired level in relationship to the voice on your PA Portable.

7. **Please note!** On some vans with daytime running lights we have noticed that there has been a possibility of noise coming through the PA. It is caused by the circuit that the van manufacturers used to dim the headlights. If you experience this, there is a quick and simple cure… turn on the headlights! Problem solved.

8. To ensure proper adhesion of the Velcro to the PA and to your dashboard, quickly clean both surfaces with rubbing alcohol but allow time for it to completely evaporate before application.

9. Enjoy your PA system. If you have any questions, please give us a call 604 644-6386 or drop us a note at info@ready2talk.ca

We offer solutions!

Box 16118 / 1199 Lynn Valley Rd. North Vancouver B.C. Canada V7J 3S9
ph 1 888 695-5351 info@ready2talk.ca www.ready2talk.ca